


Locating your Device Email Address from the Home tab [GPv3]


Lu Parente - 2015-11-12 - in How-To

Your device email address can be used to initiate communication with your device from out side of the GeoPro web app. Someone that does not have access to the GeoPro web app or just wishes to communicate via email, can use your device email address to send you 160 character **text-only** messages. Attachments, graphics and HTML should be completely avoided.

1. To locate your device email address, navigate to the **Home** tab and select **Configure**.



2. From the device configuration page, select **Advanced** from the list.



3. The **Advanced** page will display specific information pertaining to your device. Your device email address will be displayed under the **Email Address** heading.



Home



Help



Options



Log Out

[← Configure](#)

Advanced

GeoPro inReach

Device Id

300434060602870

Tenant

LP Demo PRD [Test Acct]

Device Status

Active

Provisioning Status

Provisioned

Email

Forward emails to this device



Email Address

300434060602870@geopro.globalalerting.com

SMS

SMS messages include reply link



Device Type

inReach SE

Back